

CHEMECO

17 Yale Drive,
Epping VIC 3076
Email: chemeco@iprimus.com.au

Ph: (03)9408-8699
Fax: (03)9408-8399
or visit us at www.chemeco.com.au

How to Strip the following Floors: Marble, Vinyl, Terrazzo and Concrete



Using Super Strip Plus Non Ammoniated Extra Heavy Duty Emulsifier

You will need: A dustmop or broom, wet floor signs, cardboard, wringer bucket, stripper mops (old or used are OK), black handpads, rotary scrubbing machine and black pad, rinse mops, wet vacuum or Autoscrubber

1. Sweep the floor to remove rubbish.
2. Scrape off any sticky rubbish such as gum or labels.
3. Ensure the area to be stripped is barricaded using "wet floor signs" as required by OH&S to keep people off the floor.
4. To prevent "footprints" being walked all over the floor, put a large piece of cardboard down next to the area being stripped. This way when you walk off the area being worked on, your shoes will dry on the cardboard.
5. Super Strip Plus is used in a 1:5 or 1:3 ratio depending on the build up on the floor. To 10 litres of warm water add 2 litres of Super Strip Plus or add 9 litres of warm water and 3 litres of Super Strip Plus for heavy build up.
6. The entire area has to be covered with a thick coating of the stripper solution. The best way to do this is to dip a stripper mop into the bucket of solution, remove mop from bucket, and without wringing, let the stripper pour all over the floor. If stripping a large area, divide floor into workable areas and strip one section at a time.
7. Leave stripper on the floor for five minutes ensuring that the floor stays wet by spreading with the mop if it dries or runs.
8. After five minutes, scrub the floor with a low speed scrubber (vacuum off) and blue pad for linoleum or black pads for all other flooring. As the sealer will be thicker at the edges, ensure more time is spent there.
9. Test the floor by wiping the sealer aside and scraping with a scraper to see if all the old sealer has been removed. If old sealer is still present, repeat stripping process. If all is removed, mop up or wet vacuum the slurry off the floor.
10. Using a clean mop and bucket apply Uni Clean Neutral Floor Cleaner. Mix 1 cup of Uni Clean to 10 litres of cold or lukewarm water.
11. Let floor dry. If old sealer has been removed the floor is now ready to seal.

