ARMOR PLATE LUTIONARY HARD FLOOR CARE RANGE

DAILY MAINTENANCE





Δ

ET FLO

Δ



NEVER BURNISH WITH A SOILED PAD



When Dry, if needed, burnish with ultra high speed machine and Armor Plate[™] Buffing Pad **to high gloss.**

DAILY MAINTENANCE

Remove gross soils (labels, gum). Sweep

and mop floor. Place "Wet Floor signs in

Clean & Restore

area.



Remove gross soils (labels, gum). Sweep and mop floor. Place "Wet Floor signs in area.

SCRUB & RECOAT

Approx - Once every 12 to 24 weeks



Dilute Armor Plate[™] Cutback Recoating leaner with 1 part to 12 parts water (heavy finish removal). Scrub with Armor Plate[™] Scrubbing Pad.



A 8 REST

wetting.

F I Ν

8

H

Dilute Armor Plate[™] Neutral Floor Cleaner

solution daily/ when mop becomes dirty.)

GLOSS

with 1 part to 40 parts water. (Replace

Dilute Armor Plate™ Gloss Restorer with 1 part to 60 parts water into a lined bucket



Make what you plan to use. Using a clean mop, dip into restorer and press out excess - do not use wringer.

Apply to sealed floors with a mop or auto-

scrubber. Allow floor to dry completely.

ALWAYS WEAR GOGGLES, GLOVES AND SLIP RESISTANT SHOES WHEN USING THIS PRODUCT.

> NEVER BURNISH WITH A SOILED PAD



Apply restorer as you would a finish, keeping 6" away from the edge. Allow to dry then buff with UHS burnisher and ETC Armor Plate™ Buffing Pad.



Line Bucket with fresh liner and pour

in Armor Plate™ Floor Sealer Finish.

ALWAYS WEAR GOGGLES, GLOVES AND SLIP RESISTANT SHOES WHEN USING THIS PRODUCT.



STRIP & FINISH

Approx - Once every 18 to 36 months



P

B



Remove gross soils (labels, gum). Sweep and mop floor. Place "Wet Floor signs in area.



Pick up solution with mop, wet vac or auto scrubber. Damp mop floor with clean water to remove all residue. Allow to drv before applying base coat.



scrubber or wet vac. (Replace solution when mop water becomes dirty.) Damp mop any residues with clear water. Allow floor to dry.

Line Bucket with fresh liner and pour


in Armor Plate™ Floor Sealer Finish.

Pour only what you plan to use. Use

clean finish mop. Dip into finish and

press out excess

CHEMECO



ALWAYS WEAR GOGGLES, GLOVES AND SLIP RESISTANT SHOES WHEN USING THIS PRODUCT.



Scrub floor with auto scrubber or floor machine using proper stripping pad to break softened film. Flip pad and replace as needed.



Allow 30 minutes to dry in between finish coats (maximum 4 coats in 24 hours). Last coat should cover edges.



1



To apply a full even coat, outline the area to be finished. Fill in the outlined area using a figure eight motion. Stay 6" away from edges.





Apply as many coats as required. Allow 30-45 minutes between coats, Last coat should cover edges. (To keep clean follow DAILY MAINTENANCE directions.)









R E



C 0 Pick up cleaning solution with A